

## TARGA FLORIO 1970-1973 SERIES

	NSR Porsche 908/3	Slot.IT - Policar Ferrari 312PB	Slot.IT Alfa 33T	Sloter Lola T280/T290	Fly - GB Track Chevron B19/B21	Nanno Slot Abarth 2000
<b>Body</b>	OEM with no modifications					
<b>Body Screws</b>	Open					
<b>Chassis</b>	OEM	OEM		Olifer 3D	CG Slots 3D	OEM
<b>Motor Pod</b>	OEM: NSR Sidewinder	Slot.IT Sidewinder				OEM
<b>Motor Pod Screws</b>	Open					
<b>Axle Height Screws</b>	Open					
<b>Front Bushings</b>	Open					
<b>Rear Bushings</b>	OEM	Slot.IT Spherical				OEM
<b>Front Axle</b>	OEM	OEM				OEM
<b>Rear Axle</b>	OEM	OEM				OEM
<b>Wheel Grub Screws</b>	OEM	Open				OEM
<b>Front Wheel</b>	OEM: NSR, 16x8	OEM: Slot.IT 14x8	OEM: Slot.IT 15x10	OEM: Slot.IT 14x8 or 15x8		OEM: Nanno Slot , 16x8
<b>Rear Wheel</b>	OEM: NSR, 16x8	Slot.IT: 15x8 or 16x8				OEM: Nanno Slot , 16x8
<b>Wheel Inserts</b>	OEM: NSR, Porsche	Open				OEM: Nanno Slot
<b>Axle Spacers</b>	Open					
<b>Front Tires</b>	OEM	OEM: Slot.IT 14x8	Open: 19mm, 17mm, 14mm x 8mm, 10mm			OEM
<b>Rear Tires</b>	Open: NSR 20x11	Open: D20mm x W11mm max				OEM: Nanno Slot/Any NSR
<b>Motor</b>	Open, Max 25k RPM					
<b>Motor Wires</b>	Open					
<b>Braid</b>	Open					
<b>Guide</b>	Any NSR	Open				OEM: Nanno Slot
<b>Spur Gear</b>	Any NSR Sidewinder	Open				OEM: Nanno Slot/Any NSR
<b>Spur Grub Screw</b>	OEM	Open				OEM
<b>Pinion Gear</b>	Any NSR Sidewinder	Open				OEM: Nanno Slot/Any NSR
<b>Track Power</b>	Driver Specific					
<b>Weight</b>	120gr Max					